


GT Gear Drive
Maintenance Manual
Case Sizes 1,2,3,4
Double Reduction



Equipment Reference:

For service and
information contact:

TABLE OF CONTENTS

	<i>Page</i>
Maintenance Introduction	1
<hr/>	
Disassembly	2
<hr/>	
Gear Drive	2
Input Shaft	5
Pinion Shaft	6
Output Shaft	7
Assembly	8
<hr/>	
Input Shaft	9
Pinion Shaft	10
Output Shaft	11
Gear Drive Lid	12
Gear Drive Housing	13
Gear Drive	14
Gear Drive Item List (Parts)	23
<hr/>	
Supplemental Information	
<hr/>	

TABLE OF CONTENTS

	Page
Tables	
<hr/>	
Table 1: Bolt Tightening Torque	8
 Figures	
<hr/>	
Figure 1: Removal of Gear Drive Lid	3
Figure 2: Gear Drive Housing	4
Figure 3: Input Shaft Assembly	5
Figure 4: Pinion Shaft Assembly	6
Figure 5: Output Shaft Assembly	7
Figure 6: Input Shaft Assembly	9
Figure 7: Pinion Shaft Assembly	10
Figure 8: Output Shaft Assembly	11
Figure 9A: Gear Drive Lid	12
Figure 10: Gear Drive Housing	13
Figure 11: Gear Drive Assembly	15
Figure 12: Gear Drive Assembly	16
Figure 13: Gear Drive Assembly	18
Figure 14: Gear Drive Assembly	19
Figure 15A: GT Gear Drive: Sizes 1, 2, 3, 4	22

MAINTENANCE**GEAR DRIVE**
Double Reduction

This manual contains instructions for GT gear drive disassembly and assembly. Refer to the agitator manual for all other information relative to the agitator.

Other than periodic lubrication as defined in the *Lubrication* section of the Agitator Manual, no routine operational gear drive maintenance is required.

To assure the longest life from your gear drive, annual inspections which can correspond with plant shutdowns should be planned. Bolting and the condition of all seals should be checked. Worn parts should be replaced and any areas of general concern should be brought to the attention of your local Chemineer office.

GEAR DRIVE

Double Reduction

Disassembly

Gear Drive (*Figure 15, page 22*)

1. Remove motor adapter [131] and motor. Remove the gear drive flexible coupling half [110] and key. Drain oil from gear drive. Refer to Agitator I.O.& M. Manual, *Installation*.
2. Remove outside V-ring [212] and input cap [211]. Remove inside V-ring [212].
3. Remove snap ring [210].
4. Remove the input shaft [202] assembly.
5. Remove bearing cap and shim set [223, 224].
6. Remove cover plate [254], output shaft washer, and shim set [228, 229].
7. Remove bolts [250] holding the gear drive lid [247] to the gear drive housing [248].

GEAR DRIVE

Double Reduction

Disassembly (Cont'd)

Gear Drive (Figure 15, page 22)

8. Tighten set screws [268] to break the seal between the gear drive lid [247] and housing [248]. (See Figure 1). Remove the set screws and install four jacking set screws (supplied by others).

Case Size 1 & 2 M10 x 1.5 x 50 mm (2") lg.

Case Size 3 & 4 M12 x 1.75 x 60 mm (2 1/2") lg.

Tighten jacking set screws to remove the gear drive lid [247] assembly.

9. Remove lip seal [235] and bearing [233] cup from the gear drive lid. See Figure 9A, page 12. Remove bearing cup [217] from the gear drive lid. See Figure 14, page 19.
10. Remove snap ring [236] from the output shaft [244]
11. Move the gear drive housing assembly to a press, and press the output shaft [244] assembly through the gear flange [237] and out of the gear drive housing.




Figure 1: Removal of Gear Drive Lid [247]

GEAR DRIVE

Double Reduction

Disassembly (Cont'd)

Gear Drive (Figure 15, page 22)

12. Remove gear [239] from gear flange [237].
13. Remove the pinion shaft [218] assembly from the gear drive housing.
14. Remove lip seal [249] and bearing [221, 245] cups from gear drive housing. Bearing cups mounted with an interference fit can be difficult to remove with a commercial bearing puller. Removal can be made easier by welding a 3mm (1/8") bead completely around the cup in the center of the roller race. Upon cooling, the cup will shrink allowing removal. Be sure to protect adjacent surfaces from weld spatter. Remove bearing [205].




Figure 2: Gear Drive Housing [248]

GEAR DRIVE

Double Reduction

Disassembly (Cont'd)

Input Shaft Assembly

1. Remove snap rings [204, 206].
2. Press input shaft [202] out of bearing [203].
3. Remove bearing [205] race.




Figure 3: Input Shaft Assembly [201]

GEAR DRIVE

Double Reduction

Disassembly (Cont'd)

Pinion Shaft Assembly

1. Press gear [219] and bearing [221] cone off pinion shaft [218].
2. Cut the roller cage off of bearing [217] cone. Apply bearing puller to remove the cone race.




Figure 4: Pinion Shaft Assembly [216]

GEAR DRIVE

Double Reduction

Disassembly (Cont'd)

Output Shaft

1. Remove bearing [245] cone off output shaft [244].
2. To remove bearing [245] cone, it will be necessary to cut the roller cage and remove the rollers. Hang the output shaft from the large end so the shaft is free to turn. Apply heat (acetylene torch) while turning the shaft at approximately 30 rpm or greater. When the bearing is hot enough it will start to drop off the end of the shaft. Use a screwdriver or similar tool to push the bearing off the shaft if it hangs up.

CAUTION! Heat the bearing race only. Use a small flame to avoid damage to the shaft.




Figure 5: Output Shaft Assembly [243]

The gear drive is now fully disassembled. Clean all parts and inspect for wear. Replace worn parts as required. All bearings, lip seals, and shims should be replaced with new parts. When replacing bearings, always replace both inner and outer races (cup and cone). Gears should be replaced in sets.

GEAR DRIVE

Double Reduction

Assembly

Inspect all bolts and setscrews for damage after cleaning (threads, shank, and head). If replacement is required, replace with the equivalent type and strength grade.

Inspect and clean all tapped holes. If threads are damaged, chase with an appropriate tap.

NOTE: The following assembly procedures require the use of a torque wrench. The values listed in Table 1 are proper tightening torques as a function of thread size.

Bearing [217, 221, 233, and 245] cones are mounted with interference fits. Heat the cones and press onto the shaft. Heat bearings in oven or oil bath.

NOTE: Do not heat parts in excess of 135° C (275°F). Do not apply direct flame. Do not allow parts to touch the bottom or sides of the oven or oil bath.

Bearing [221, 233, and 245] cups are mounted with interference fits. Press bearing cups into their housing cold. Placing the cups in dry ice will cause them to shrink and ease installation.

Install lip seals with the seal lip towards the bearing. Coat the seal lip with bearing grease prior to installing the shaft.

TABLE 1: BOLT TIGHTENING TORQUE FOR CARBON STEEL				
Bolt Size	Grade 8.8		Grade 10.9	
	Nm	Ft-lb	Nm	Ft-lb
M6 x 1	9.9	7.3	12	8.8
M8 x 1.25	14	18	29	21
M10 x 1.5	48	35	58	43
M12 x 1.75	80	59	101	75

Lubricate all fasteners at assembly with grease, oil or an anti-seize material. Bolt threads and contact surfaces of bolt heads and nuts should be lubricated.

If fasteners cannot be lubricated, multiply table values by 1.33.

GEAR DRIVE

Double Reduction

Assembly (Cont'd)

Input Shaft

1. Press bearing [205] race onto input shaft [202].
2. Press bearing [203] onto the input shaft.

NOTE: Bearing [203] has a shield on one side. Install bearing with the shield towards the keyed end of the shaft.

3. Install snap rings [204,206].




Figure 6: Input Shaft Assembly [201]

GEAR DRIVE

Double Reduction

Assembly (Cont'd)

Pinion Shaft

1. Install key [220] into pinion shaft [218]. Heat gear [219] and press onto the pinion shaft.

Note: Do not heat gear in excess of 135°C (275°F). Do not apply direct flame. Do not allow the gear to touch the bottom or sides of the oven or oil bath.

2. Heat bearing [217, 221] cones and press onto pinion shaft. The gear and bearing cones must be firmly seated against their respective shoulders. Check with a feeler gauge.




Figure 7: Pinion Shaft Assembly [216]

GEAR DRIVE

Double Reduction

Assembly (Cont'd)

Output Shaft Assembly

1. Heat bearing [245] cone and press onto the output shaft [244]. The bearing cone must be firmly seated against the shaft shoulder. Check with a feeler gauge.




Figure 8: Output Shaft Assembly [243]

GEAR DRIVE

Double Reduction

Assembly (Cont'd)

Gear Drive Lid

1. Install lip seal [235] in the gear drive lid [247].
2. Press bearing [233] cup into the gear drive lid. The bearing cup must be firmly seated against the lid shoulder. Check with a feeler gauge.




Figure 9A: Gear Drive Lid [247]

GEAR DRIVE

Double Reduction

Assembly (Cont'd)

Gear Drive Housing

1. Coat bearing [205, 221] housing bores with loctite #290. Press bearing [205] and bearing [221] cup into the gear drive housing [248].
2. Press bearing [245] cup into gear drive housing. The cup must be firmly seated against the housing shoulder. Check with a feeler gauge.
3. Install lip seal [249] in the gear drive housing.




Figure 10: Gear Drive Housing [248]

GEAR DRIVE

Double Reduction

Assembly (Cont'd)

Gear Drive (Figure 11, page 15)

1. Cut a 200mm (8") diameter x 10mm (½") thick disc of plywood. .
2. Set output shaft assembly [243] onto the plywood disc, large end down.
3. Raise the gear drive housing [248] and center the output shaft bore over the output shaft assembly. Carefully lower the gear drive housing until bearing [245] is seated.
4. Shim under gear drive housing to center the output shaft in the housing bore.
5. Install pinion shaft assembly [216]. Place gear [239] over the housing drywell, rest the gear on the pinion shaft assembly gear.

Note: Pinion shaft assembly must be installed before gear is placed into gear drive housing.

6. Place key [238] into the output shaft keyway.
7. Heat gear flange [237] to 200°C (400°F) and press onto the output shaft.
8. Allow the gear flange to cool. Assemble snap ring [236] to the output shaft.

GEAR DRIVE

Double Reduction

Assembly (Cont'd)

Gear Drive




Figure 11: Gear Drive Assembly

GEAR DRIVE

Double Reduction

Assembly (Cont'd)

Gear Drive

9. Lift the gear [239] to engage tenon. Install bolts and lockwashers [240, 241]. Torque bolts to the value shown in *Table 1, page 8*.




Figure 12: Gear Drive Assembly

GEAR DRIVE
Double Reduction

Assembly (Cont'd)**Gear Drive** (Figure 13, page 18)

10. Apply RTV sealant, Three Bond #1215AA or equal, to the gear drive housing [248] flange.
11. Assemble gear drive lid [247] to the gear drive housing [248].
12. Install dowel pins [252] flush with the top of the gear drive lid flange. Install bolts and lockwashers [250, 251]. Torque bolts to the value shown in *Table 1, page 8*.
13. Heat bearing [233] cone and press onto the output shaft [244]. Ensure that the bearing cone is firmly seated in its cup. Allow bearing to cool.
14. Remove the plywood disc from under the output shaft.
15. Place a nylon strap under the output shaft washer [228] and secure with two bolts [230]. Place a dial indicator stem on the face of bearing [233] cone and lift the shaft to measure the bearing end play. Record this measurement "A".
16. Remove the nylon strap, measure the distance with a depth micrometer from the bearing cone face to the end of the output shaft. *See insert, Figure 13*. Record this measurement "B".
17. Calculate the required shim set [229] thickness.

$$\text{Required shim set thickness} = B - A - .051\text{mm} (.002\text{"}).$$

18. Count out the required number of new shims.

Red = .051mm (.002") thick

Blue = .127mm (.005) thick

19. The final end play setting should be .0mm (.000") end play to .075mm (.003") preload.

GEAR DRIVE
Double Reduction

Assembly (Cont'd)

Gear Drive

20. Install shim set [229]. Install output shaft washer [228] with bolts and lockwashers [230, 231]. Torque bolts to the value shown in *Table 1, page 8*.




Figure 13: Gear Drive Assembly

GEAR DRIVE

Double Reduction

Assembly (Cont'd)

Gear Drive

21. Install bearing [217] cup. Install bearing cap [223] without bolts.
22. Apply hand pressure to bearing cap [223] to avoid movement and measure the gap between the bearing cap and the gear drive lid [247]. Count out new shims equal to the measured gap plus .051mm (.002") to provide a bearing setting of .0 mm (.000") to .051mm (.002") end play.

Red = .051mm (.002") thick
Blue = .127mm (.005") thick




Figure 14: Gear Drive Assembly

GEAR DRIVE

Double Reduction

Assembly (Cont'd)

Gear Drive

23. Install shim set **[224]**. Install bolts and lockwashers **[225, 226]**. Torque bolts to the value shown in *Table 1, page 8*.
24. Apply RTV sealant, Three Bond #1215AA or equal, to cover plate **[254]**. Assemble to the gear drive lid with bolts and lockwashers **[255, 256]**. Torque bolts to the value shown in *Table 1*.
25. Install input shaft **[202]** assembly. Carefully lower into the housing. Turn the shaft as the assembly is lowered to allow the pinion to mesh with its gear.
26. Install snap ring **[210]**.
27. Install one V-ring **[212]** onto gear drive input shaft with sealing lip facing up. Position V-ring just below step on shaft. Slide input cap **[211]** down gear drive input shaft (to push V-ring into operating position) until cap rests on gear drive lid mounting surface. Remove input cap **[211]**.
28. Apply RTV sealant, Three Bond #1215AA or equal, to input cap **[211]**. Assemble to the gear drive lid with bolts and lockwashers **[213, 214]**. Torque bolts to the value shown in *Table 1*.
29. Install one V-ring **[212]** with sealing lip against the input cap. Rotate the input shaft by hand until the output shaft makes at least one revolution. Check for any binding.
30. Add grease to bearings **[233, 245]** and fill the gear drive housing with oil. *See Agitator I.O.&M. Manual, Lubrication.*
31. Install gear drive flexible coupling half **[110]**. *See Agitator I.O.&M. Manual, Installation.*
32. Install motor adapter **[131]** and motor **[100]**. *See Agitator I.O.&M. Manual, Installation.*

This page intended to be blank




Figure 15A: GT Gear Drive: Sizes 1,2,3,4

GEAR DRIVE ITEM LIST
Double Reduction Sizes 1,2,3,4

Item #	Description	Qty.	Item #	Description	Qty.	Item #	Description	Qty.
200	gear drive assembly	1	228	output shaft washer	1	248-001	gear drive housing	1
201	input shaft assembly	1	229	shim set	1		double reduction	
202	input shaft	1	230	bolt	3	249	lip seal	1
203-001	bearing (shield one side)	1	231	lockwasher	3	250	bolt	11
204	snap ring	1				251	lockwasher	11
205-001	bearing	1	233	bearing	1	252	dowel pin	2
206	snap ring	1						
210	snap ring	1	235	lip seal	1	254	cover plate	1
211	input cap	1	236	snap ring	1	255	bolt	3
212	V-ring	2	237	gear flange	1	256	lockwasher	3
213	bolt	4	238	key	1			
214	lockwasher	4	239	gear	1	258	dipstick	1
			240	bolt	8	259	oil fill plug, NPT	1
			241	lockwasher	8	260	grease fitting	1
216	pinion shaft assembly	1				261	relief fitting	1
217	bearing	1	243	output shaft assembly	1	262	grease fitting	1
218	pinion shaft	1	244	output shaft	1	263	pipe plug, NPT	1
219	gear	1	245	bearing	1	264	magnetic drain plug, NPT	1
220	key	1						
221	bearing	1	247-001	gear drive lid	1	265	pipe plug, NPT	1
				double reduction		266	pipe plug, NPT	1
223	bearing cap	1				267	pipe plug, NPT	1
224	shim set	1				268	set screw	4
225	bolt	4				269	input shaft key	1
226	lockwasher	4				270	breather	1
						271	elbow fitting	1



P.O. Box 1123
Dayton, Ohio 45401
Phone: (937) 454-3200
FAX: (937) 454-3375

www.chemineer.com

© Chemineer, Inc. 2004