



MISSION Liner Bore Gauges

Knowing when to replace your mud pump liners doesn't have to be a complicated process.

MISSION™ Liner Bore Gauges can help you easily identify when your liners need replacement due to wear. These easy-to-use, effective tools are placed within the mud pump liners to assess the current bore diameter. When the liner gauge can be flipped over past the 90° point, the liner is worn out and needs to be replaced.

Our liner bore gauges are compatible for most types of mud pump liners.

Legacy Part Number	OID	Description
X151940	10350555-001	Gage, Liner 4½ in.
X151994	10350558-001	Gage, Liner 5 in.
X151998	10350561-001	Gage, Liner 5½ in.
X151993	10350557-001	Gage, Liner 6 in.
X151944	10350556-001	Gage, Liner 6½ in.
X151996	10350560-001	Gage, Liner 7 in.