


## RELEASE NOTES

	Product	Version	Release Date	Changes	Descriptions
	iPS2	3.33	6/8/2017	Improvement/ Fixes	<ul style="list-style-type: none"> <li>• Added support for generic variables</li> <li>• Added ability to manually switch BAT2 on or off when BAT2 was connected first in the tool string</li> <li>• Correct message that could mistakenly inform iMCU that BAT2 turned on</li> </ul>
		3.32	2/28/2017	Bug Fixes	<ul style="list-style-type: none"> <li>• Update to detect and correct memory logging issue (log pointer error)</li> </ul>
		3.30	5/5/2015	Improvement/ Fixes	<ul style="list-style-type: none"> <li>• Improvement to the way pull and hold voltage is displayed in ToolTracker</li> <li>• Change to allow either BAT 1 or BAT 2 to be connected to Directional Module first, and maintain proper battery switching</li> <li>• Fixed pull current data logging and display issue</li> </ul>
		3.20	9/17/2014	Bug Fixes	<ul style="list-style-type: none"> <li>• Fixes memory wrap issues</li> <li>• Corrects Battery 2 reporting</li> </ul>
		2.00	12/19/2012	New Features/ Enhancements	<ul style="list-style-type: none"> <li>• Initial Release</li> </ul>